
List of tables

Table 1	
Initial system installation—list of tasks in subsections	14
Table 2	
Wire gauge requirements with two 30-amp feeds (five wires)	55
Table 3	
Order codes for BIX designation strips	70
Table 4	
MDF cross-connections for PFTU operations	88
Table 5	
NT8D22 switch settings for a single-column system	93
Table 6	
Switch settings for master in multiple-column system	94
Table 7	
Switch settings for slaves in multiple-column system	94
Table 8	
SW2 on master—total number of slaves in the system	95
Table 9	
SW2 on each slave—unit number for the slave	96
Table 10	
NT8D22 System Monitor— pin assignments at J3	100
Table 11	
NT8D22 System Monitor— pin assignments at J4	101
Table 12	
Alarm and trip lead connections—NT8D46AV cable	103

Table 13	
NT7D15 System Monitor—system monitor to MDF cable pin assignments at the MDF	105
Table 14	
SBE to 3PE cable assignment—use NT8D80 cables	150
Table 15	
IGS to InterGroup cable assignment—use NT8D76 cables	151
Table 16	
Typical CNI configuration (option 81)	159
Table 17	
CNI backplane connector positions—NTND14 cables	162
Table 18	
CNI to 3PE connections—NTND14 cables	168
Table 19	
IGS to InterGroup cable assignment—use NT8D76 cables	169
Table 20	
Typical CNI configuration (option 81C)	175
Table 21	
CNI backplane connector positions—NTND14 cables	178
Table 22	
CNI to 3PE NTND14 cable connections for Core/Net 1	184
Table 23	
CNI to 3PE NTND14 cable connections for Core/Net 0	185
Table 24	
IGS to InterGroup cable assignment—use NT8D76 cables	186
Table 25	
NT8D04 network loop configurations	200
Table 26	
NT8D11 cable connections	218
Table 27	
NT8D37 cable connections	219

Table 28	
Line and trunk pair-termination tables	227
Table 29	
NT8D11 CE/PE Module: line card pair-terminations	228
Table 30	
NT8D11 CE/PE Module: NT8D14 Universal Trunk Card pair-terminations	229
Table 31	
NT8D11 CE/PE Module: NT8D15 E&M Trunk Card 2-wire paging mode pair-terminations	230
Table 32	
NT8D11 CE/PE Module: NT8D15 E&M Trunk Card 2-wire type 1 mode pair-terminations	230
Table 33	
NT8D11 CE/PE Module: NT8D15 E&M Trunk Card 4-wire type 1 and type 2 mode pair-terminations	231
Table 34	
NT8D11 CE/PE Module: NT8D15 E&M Trunk Card 4-wire type 1 and type 2 mode pair-terminations	232
Table 35	
NT8D11 CE/PE Module: NT5K17 Direct Dial Inward Trunk Card pair terminations for I/O panel connector A	233
Table 36	
NT8D11 CE/PE Module: NT5K17 Direct Dial Inward Trunk Card pair terminations for I/O panel connectors B, E, H	234
Table 37	
NT8D11 CE/PE Module: NT5K17 Direct Dial Inward Trunk Card pair terminations for I/O panel connectors C, F, K	236
Table 38	
NT8D11 CE/PE Module: NT5K18 Flexible Central Office Trunk Card pair terminations for I/O panel connector A	238

Table 39	
NT8D11 CE/PE Module: NT5K18 Flexible Central Office Trunk Card	
pair terminations for I/O panel connectors B, E, H	239
Table 40	
NT8D11 CE/PE Module: NT5K18 Flexible Central Office Trunk Card	
pair terminations for I/O panel connectors C, F, K	241
Table 41	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 2W Paging mode	
pair terminations for I/O panel connector A	243
Table 42	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 2W Paging mode	
pair terminations for I/O panel connectors B, E, H	244
Table 43	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 2W Paging mode	
pair terminations for I/O panel connectors C, F, K	245
Table 44	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 2W Type 1 mode	
pair terminations for I/O panel connector A	246
Table 45	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 2W Type 1 mode	
pair terminations for I/O panel connectors B, E, H	247
Table 46	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 2W Type 1 mode	
pair terminations for I/O panel connectors C, F, K	248
Table 47	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 4W Type 1 mode	
pair terminations for I/O panel connector A	249
Table 48	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 4W Type 1 mode	
pair terminations for I/O panel connectors B, E, H	250
Table 49	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card 4W Type 1 mode	
pair terminations for I/O panel connectors C, F, K	251

Table 50	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card AC15 Trunk mode	
pair terminations for I/O panel connector A	253
Table 51	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card AC15 Trunk mode	
pair terminations for I/O panel connectors B, E, H	254
Table 52	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card AC15 Trunk mode	
pair terminations for I/O panel connectors C, F, K	255
Table 53	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card Recorded Announcement mode pair terminations for I/O panel connector A . . .	256
Table 54	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card Recorded Announcement mode pair terminations for I/O panel connectors B, E, H	257
Table 55	
NT8D11 CE/PE Module: NT5K19 E&M Trunk Card Recorded Announcement mode pair terminations for I/O panel connectors C, F, K	258
Table 56	
NT8D13 PE Module: line card pair-terminations for connectors A, C, E, and G (single loop mode)	259
Table 57	
NT8D13 PE Module: line card pair-terminations for connectors B, D, and F (single loop mode)	260
Table 58	
NT8D13 PE Module: line card pair-terminations for connectors A, C, E, and G (dual loop mode)	261
Table 59	
NT8D13 PE Module: line card pair-terminations for connectors B, D, and F (dual loop mode)	262

Table 60	
NT8D13 PE Module: QPC71 E&M//DX Trunk pair-terminations . . .	263
Table 61	
NT8D13 PE Module: QPC74 Recorded Announcement Trunk pair-terminations	264
Table 62	
NT8D13 PE Module: QPC237 4-wire E&M//DX Trunk pair-terminations	265
Table 63	
NT8D13 PE Module: QPC239 Recorded Telephone Dictation Trunk pair-terminations	266
Table 64	
NT8D13 PE Module: QPC250 Release Line Trunk pair-terminations	266
Table 65	
NT8D13 PE Module: QPC449 Loop Signaling Trunk and QPC450 CO/FX/WATS Trunk pair-terminations	267
Table 66	
NT8D13 PE Module: Announcement and Music Trunk pair-terminations	268
Table 67	
NT8D37 IPE Module: line card pair-terminations	269
Table 68	
NT8D37 IPE Module: NT8D14 Universal Trunk Card pair-terminations	270
Table 69	
NT8D37 IPE Module: NT8D15 E&M Trunk Card 2-wire paging mode pair-terminations	271
Table 70	
NT8D37 IPE Module: NT8D15 E&M Trunk Card 2-wire type 1 mode pair-terminations	271
Table 71	
NT8D37 IPE Module: NT8D15 E&M Trunk Card 4-wire type 1 and type 2 mode pair-terminations	272

Table 72	
NT8D37 IPE Module: NT8D15 E&M Trunk Card 4-wire type 1 and type 2 mode pair-terminations	273
Table 73	
NT5K17 Direct Dial Inward Trunk connections for NT8D37 I/O panel connectors A, E, K, R	274
Table 74	
NT5K17 Direct Dial Inward Trunk connections for NT8D37 I/O panel connectors B, F, L, S	275
Table 75	
NT5K17 Direct Dial Inward Trunk connections for NT8D37 I/O panel connectors C, G, M, T	277
Table 76	
NT5K18 Flexible Central Office Trunk connections for NT8D37 I/O panel connectors A, E, K, R	279
Table 77	
NT5K18 Flexible Central Office Trunk connections for NT8D37 I/O panel connectors B, F, L, S	280
Table 78	
NT5K18 Flexible Central Office Trunk connections for NT8D37 I/O panel connectors C, G, M, T	282
Table 79	
NT5K19 Flexible E&M 2-Wire Type 1 connections for NT8D37 I/O panel connectors A, E, K, R	284
Table 80	
NT5K19 E&M 2-Wire Type 1 connections for NT8D37 I/O panel connectors B, F, L, S	285
Table 81	
NT5K19 Flexible E&M 2-Wire Type 1 trunk connections for NT8D37 I/O panel connectors C, G, M, T	286
Table 82	
NT5K19 Flexible E&M 2-Wire Paging trunk connections for NT8D37 I/O panel connectors A, E, K, R	287

Table 83	
NT5K19 Flexible E&M 2-Wire Paging trunk connections for NT8D37 I/O panel connectors B, F, L, S	288
Table 84	
NT5K19 Flexible E&M 2-Wire Paging trunk connections for NT8D37 I/O panel connectors C, G, M, T	289
Table 85	
NT5K19 Flexible E&M 2-Wire Recorded Announcement trunk connections for NT8D37 I/O panel connectors A, E, K, R	290
Table 86	
NT5K19 Flexible E&M 2-Wire Recorded Announcement trunk connections for NT8D37 I/O panel connectors B, F, L, S	291
Table 87	
NT5K19 Flexible E&M 2-Wire Recorded Announcement trunk connections for NT8D37 I/O panel connectors C, G, M, T	292
Table 88	
NT5K19 Flexible E&M 4-Wire Type 1 connections for NT8D37 I/O panel connectors A, E, K, R	293
Table 89	
NT5K19 Flexible E&M 4-Wire Type 1 connections for NT8D37 I/O panel connectors B, F, L, S	294
Table 90	
NT5K19 Flexible E&M AC15 trunk connections for NT8D37 I/O panel connectors A, E, K, R	296
Table 91	
NT5K19 Flexible E&M AC15 Trunk connections for NT8D37 I/O panel connectors B, F, L, S	297
Table 92	
Pair-terminations for NT5K11 EEPE Module I/O panel connectors A, C, E (single loop mode) Shelf Section-A	298
Table 93	
Pair-terminations for NT5K11 EEPE Module I/O panel connectors B, D, F (single loop mode) Shelf Section-A	300

Table 94	
Pair-terminations for NT5K11 EEPE Module I/O panel connectors G, I, L (single loop mode) Shelf Section-A	302
Table 95	
Pair-terminations for NT5K11 EEPE Module I/O panel connectors H, K, M (single loop mode) Shelf Section-A	304
Table 96	
Pair-terminations for NT5K11 EEPE Module I/O panel connectors A, C, E, (dual loop mode) Shelf Section-A	306
Table 97	
Pair-terminations for NT5K11 EEPE Module I/O panel connectors B, D, F (dual loop mode) Shelf Section-A	308
Table 98	
Pair-terminations for NT5K11 EEPE Module I/O panel connectors G, I, K (dual loop mode) Shelf Section-A	310
Table 99	
Pair-terminations for NT5K11 EEPE Module I/O panel connectors H, L, M (dual loop mode) Shelf Section-A	312
Table 100	
Seismic Bracing Kits	343
Table 101	
Seismic Anchor Kit	344
Table 102	
Anchor hole sizes	346
Table 103	
Connector C pin assignments (receive signal cable)	370
Table 104	
Connector D pin assignments (transmit signal cable)	371
Table 105	
Connector E pin assignments	372
Table 106	
Connector F pin assignments	373

Table 107	
QPC62 switch settings	379
Table 108	
QPC99 A20 switch and F25 pad switch	381
Table 109	
QPC99 S2 switch	381
Table 110	
NT8D22 System Monitor switch settings for slaves	382
Table 111	
SW2 on each slave—unit number for the slave	383
Table 112	
Equipment dimensions	417
Table 113	
Rectifier settings	424
Table 114	
Cabling to connect a QBL15 to batteries	425
Table 115	
Cabling to add a second QBL15	427
Table 116	
Cabling to connect NT0R72 rectifiers to the QBL15 distribution box	430
Table 117	
NT6D82 alarm and trip lead connections—NT8D46AV cable	451
Table 118	
QBL12 alarm and trip lead connections—NT8D46AW cable	452
Table 119	
QBL15 alarm and trip lead connections—NT8D46AT cable	453
Table 120	
QCA13 alarm and trip lead connections—NT8D46AV cable	453
Table 121	
NT8D11 cable connections for 7-cable configuration	468

Table 122	
NT8D37 cable connections for 12-cable configuration	470
Table 123	
Line and trunk pair-termination tables	473
Table 124	
NT8D11 CE/PE Module: line card pair-terminations for connectors A, B, E, and H (7-cable)	474
Table 125	
NT8D11 CE/PE Module: line card pair-terminations for connectors C, F, and K (7-cable)	475
Table 126	
NT8D11 CE/PE Module: NT8D14 pair-terminations for connectors	476
Table 127	
NT8D11 CE/PE Module: NT8D14 pair-terminations for connectors C, F, and K (7-cable)	477
Table 128	
NT8D11 CE/PE Module: NT8D15 2-wire paging mode pair-terminations for connectors A, B, E, and H (7-cable)	478
Table 129	
NT8D11 CE/PE Module: NT8D15 2-wire paging mode pair-terminations for connectors C, F, and K (7-cable)	478
Table 130	
NT8D11 CE/PE Module: NT8D15 2-wire type 1 mode pair-terminations for connectors A, B, E, and H (7-cable)	479
Table 131	
NT8D11 CE/PE Module: NT8D15 2-wire type 1 mode pair-terminations for connectors C, F, and K (7-cable)	479
Table 132	
NT8D11 CE/PE Module: NT8D15 4-wire type 1 and type 2 mode pair-terminations for connectors A, B, E, and H (7-cable)	480

Table 133	
NT8D11 CE/PE Module: NT8D15 4-wire type 1 and type 2 mode pair-terminations for connectors C, F, and K (7-cable)	481
Table 134	
NT8D37 IPE Module: line card pair-terminations for connectors A, E, K, and R (12-cable)	482
Table 135	
NT8D37 IPE Module: line card pair-terminations for connectors B, F, L, and S (12-cable)	483
Table 136	
NT8D37 IPE Module: line card pair-terminations for connectors C, G, M, and T (12-cable)	484
Table 137	
NT8D37 IPE Module: NT8D14 pair-terminations for connectors A, E, K, and R (12-cable)	485
Table 138	
NT8D37 IPE Module: NT8D14 pair-terminations for connectors B, F, L, and S (12-cable)	486
Table 139	
NT8D37 IPE Module: NT8D14 pair-terminations for connectors C, G, M, and T (12-cable)	487
Table 140	
NT8D37 IPE Module: NT8D15 2-wire paging mode pair-terminations for connectors A, E, K, and R (12-cable)	488
Table 141	
NT8D37 IPE Module: NT8D15 2-wire paging mode pair-terminations for connectors B, F, L, and S (12-cable)	488
Table 142	
NT8D37 IPE Module: NT8D15 2-wire paging mode pair-terminations for connectors C, G, M, and T (12-cable)	489
Table 143	
NT8D37 IPE Module: NT8D15 2-wire type 1 mode pair-terminations for connectors A, E, K, and R (12-cable)	489

Table 144	
NT8D37 IPE Module: NT8D15 2-wire type 1 mode pair-terminations for connectors B, F, L, and S (12-cable)	490
Table 145	
NT8D37 IPE Module: NT8D15 2-wire type 1 mode pair-terminations for connectors C, G, M, and T (12-cable)	490
Table 146	
NT8D37 IPE Module: NT8D15 4-wire type 1 and type 2 mode pair-terminations for connectors A, E, K, and R (12-cable)	491
Table 147	
NT8D37 IPE Module: NT8D15 4-wire type 1 and type 2 mode pair-terminations for connectors B, F, L, and S (12-cable)	492
Table 148	
NT8D37 IPE Module: NT8D15 4-wire type 1 and type 2 mode pair-terminations for connectors C, G, M, and T (12-cable)	493
Table 149	
NT8D11 cable connections: expanded configuration	496
Table 150	
NT8D37 cable connections: expanded configuration	498

